



Hello, I've arrived!

Now that I'm here you are only one
flat-pack away from transforming
your home.



Mocka.

Thank you for supporting us.

We believe design belongs to everyone. From materials and processes to safety testing, production and delivery, we are passionate and committed to bringing you the best possible product so you can create beautifully functional spaces to feel comfortably you.

Here are a few assembly tips before you get started:



Make Time

The first step to all seamless assembly is taking a moment to carefully read through the instructions—you are already on your way to creating a beautifully functional space!



Set The Mood

Put on your favourite playlist, order that pizza and pour yourself a drink to get in the mood!



Tool Check

Layout the instructions, screws and panels to check you have everything you need. A blanket or soft floor rug will help protect your new favourite item from scratches and a drill will speed up the assembly too!



Room Reveal

You did it! Take a step back and enjoy the moment. Don't forget to recycle any packaging and share a pic of your room reveal—we love seeing how you transform your home! **Tag us @mockaaustralia/@mockaanz**

Happy flat-packing!

The Mocka Team

Need help? Our Support Team are available via live chat, email or phone. Visit our website for details.

AUSTRALIA

+61 7 3184 8466

Our phone lines are available
weekdays 9am to 5pm AEST



NEW ZEALAND


+64 3 384 1858

Our phone lines are available
weekdays 9am to 5pm NZT

Leeroy

Buffet

Thank you for your purchase. Please follow the instructions for correct assembly. While we took great effort to ensure these assembly instructions were correct at the time of printing, sometimes updates are required post production. For the most up to date versions please refer to the product page on our website.
mocka.com.au/mocka.co.nz



WARNING

Children have died from furniture toppling over.




- **ALWAYS** secure this furniture with an anchor device.
- **NEVER** allow children to stand, climb or hang on drawers, doors or shelves.
- **ALWAYS** secure your television with an anchor device.

Leeroy




Buffet

Panel Layout



Leeroy

Buffet






Phillips & Flathead screwdrivers
and hammer required


For quicker assembly, we recommend the
use of a power drill on a low-speed setting.

Leeroy




Buffet


- 1** *Please assemble it on a rug or other soft surface to avoid marking.

Hardware Needed		
A		x8
M		x2
N		x2



2


Hardware Needed		
D		x9
P		x3
Q		x3



Leeroy


Buffet

3



Hardware Needed		
A		x6
D		x6
CL		x1
CR		x1

4







Hardware Needed		
A		x4
D		x6
CL		x1
CR		x1


Leeroy

Buffet

5



Hardware Needed


A		x4
D		x6
CL		x1
CR		x1



6

Hardware Needed

B		x4
R		x4



Leeroy

Buffet


7

Hardware Needed

B



x4



8


Hardware Needed

B




x6

C




x2





Leeroy

Buffet


9



Hardware Needed

B		x8
C		x8


10






Leeroy

Buffet


11





Hardware Needed

J		x8
L		x4
T		x1

12




Hardware Needed

C		x8
G		x8




Leeroy


Buffet

13




Hardware Needed



K		x8
S		x2
T		x1




14



Hardware Needed

E		x12
F		x12



Leeroy

Buffet


15

Hardware Needed

V



x12



16

Hardware Needed

U



x12

H




x2

I



x4



Leeroy

Buffet


17

Hardware Needed

U



x8




18

Hardware Needed

U







x16



Leeroy

Buffet




Leeroy

Buffet


19

Hardware Needed

A




x15




20

Hardware Needed

G




x15




Leeroy

Buffet

21



22



Hardware Needed

B







x15

Leeroy



Buffet

23



Hardware Needed		
D		x18
DL		x3
DR		x3

24






Leeroy

Buffet


25

Hardware Needed

G		x2
O		x2



26





Love it for longer.

Remove all liquid and food spills immediately ONLY with a clean, damp, undyed white cloth.
Do NOT use abrasives or common household detergents.



Caring for our world.

In the interest of our environment, please dispose of all packaging thoughtfully.



Good news, you're all done!

Love it and share it on Instagram by tagging

 @mockaaustralia | @mockanz