



INSTALLATION MANUAL




KARIZMA luce

CASA M Swing



RoHS

150mA @ 34V | AC220-240V | 50/60Hz | IP44
Die cast | Adjustable



Do not operate with power supply connected.

<p>1</p>	<p>2</p> <p>Ø60</p> <p>Cut a hole in the ceiling with a diameter of 60mm.</p>	<p>3</p> <p>3-1 Red</p> <p>3-2 Black</p> <p>3-3</p> <p>AC220-240V</p> <p>Connect the power supply (AC220-240V)</p>
<p>5</p> <p>Hold the spring clip by hand and install it in the hole.</p>	<p>6</p> <p>Fixed drive box, the installation is complete.</p>	<p>7</p> <p>Switch on the power.</p>
<p>8</p>		

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.