

 Single sided roll-up made of lacquered bamboo. With 3-part pole - very easy to assemble. Cassette in square design with 2 feet - 30 cm long. Open the end cap on the top profile by mounting of the banner. Take out the white list and stick the banner on - turn once - and push the list with banner into the profile. Incl. strong, dark green bag. Recommended for indoor use.

 Einseitiges Roll-up aus lackiertem Bambus. Mit 3-teiligem Stange - einfache Montage. Kassette in quadratisches Design mit 2 Füßen - 30 cm lang. Bei Montage des Banners die Endkappe am Oberprofil öffnen. Nehmen Sie die kleine Liste heraus und das Banner aufkleben. Ein mal runddrehen und die Liste reinschieben in das Profil. Inkl. kräftige, dunkelgrüne Tasche. Empfohlen für den Innenbereich.

 Enkelt-sided roll-up udført i lakeret bambus. Med 3-delt stang - let at samle. Kassette i firkantet design med 2 fødder - 30 cm lange. Ved montering af banneret åbnes endekappen på topprofilen. Tag den hvide liste ud og klæb banneret på - drej en enkelt gang rundt og skub banner og liste ind i profilen. Inkl. kraftig, mørkegrøn taske. Anbefales til indendørs brug.

Top bleed: 3 cm (not visible)

## PRINT INFO

**Total banner size:**  
85 x 206 cm

**Visible graphic:**  
85 x 200 cm

Bottom bleed: 3 cm (not visible)

↑

206 cm

↓



**Bannermaterial**  
We recommend 250-350 g polyester



Model	Article	Banner size	Visible Banner	Colour	Total W x H	Weight
342	4469	85 x 206 cm	85 x 200 cm	Bamboo	89,5 x 210 cm	4,5 kg

 **Instructions for mounting the banner**

 **Anleitung zur Montage des Banners**

 **Instruktion til monteringen af banner**



### Bannermaterial

We recommend 250-350 g polyester

### Total banner size

85 x 206 cm

### Visible graphic size

85 x 200 cm

### Bottom bleed

3 cm will roll into the base

### Top bleed

3 cm will be inside the banner rail




Incl. green bag



### Product Parts:

- 1-Base
- 2-Banner Rail
- 3-Top pole with plug
- 4-Middle pole
- 5-Bottom pole with adjustment screw
- 6-Pin



**\*Do not pull pin (6) until directed in Step 3**

### Step 1

Take all parts out of the bag. Place the banner on a flat surface.

Flip open the end of the Banner Rail (2) and take out the banner rail insert. Remove protective cover from adhesive supplied on banner rail banner. Carefully line up Banner Rail Insert with the top of the banner (on the back) and press firmly. Roll the banner so that it makes a full turn around the banner rail insert. Slide top of banner attached to Banner Rail insert, inside of the banner rail.



### Step 2

Lay banner flat, printed side up. On the Base (1) you will find a leader with a stripe of adhesive. Firmly and evenly press the bottom of the banner onto the adhesive. Be sure to smooth out any bubbles or wrinkles. It is recommended to use an additional two short strips of adhesive tape as show in picture.



### Step 3

Maintain tension while slowly removing the pin(6). Allow the banner to gently roll into the Base(1).



### Step 4

Lay the Base(1) on the floor and flip onto its back. Rotate the feet perpendicular to the base. Make sure the hole in the foot is at the back of the banner. Flip Base(1) right side up.



### Step 5

Being sure to line up the notched edge of each pole with the gripper in the plastic joint, insert wood end of the middle pole(4) into the plastic joint of the bottom pole(5). Do the same with the wood end of the top pole (3) and the plastic joint on the middle pole(4).



### Step 6

Insert the bottom of assembled pole (3+4+5), (hook end up) into the hole in the foot of the base(1).



### Step 7

Stand facing the back of the base(1).

Holding the Pole(3+4+5), pull the banner rail(2) and step backwards. Tilt the unit onto its back and step backwards until you can place the hole in the banner rail (2) securely over the plug on the top of the Pole (3+4+5). Stand the unit upright.